

Disable Aid for Toilet



Find a steel frame chair with armrests. I found one on the nature strip free recycling program.



Cut at '1' for the correct height. Remove the back at '2'.

It is a good idea to reinforce the corners at '3' using the offcuts. Bend at '4' using a pipe or tube bender to make the back wider. If you do not have a pipe bender, party cut and re-weld.

