

Caravan cover tie downs

Use a number of treated pine 70 x 5 x 2200 mm with eye-bolts at the ends. Screw clips on the bottom of the van floor, use ropes with a loop at one end to hold down the van cover/tarps. This stops the cover blowing in the wind.



Caravan Cover Tie Downs



Clip